

What's Included

With Valentine One Radar Locator:

1. Valentine One Radar Locator
2. Windshield mount
3. Visor mount
4. Lighter adapter
5. Power cord, coiled
6. Power cord, straight
7. Spare suction cups
8. Direct-wire power adapter
9. Wiring-harness connector
10. Owner's Manual
11. Spare fuse

With the Concealed Display:

(optional at extra cost)

1. Straight power cord, 8-foot
2. Straight power cord, 3-inch
3. Display-module backplate, for mounting
4. Dual Lock® Fasteners

With the Remote Audio Adapter:

(optional at extra cost)

1. Power cord, straight

Starting Up

Valentine One has been designed for easy operation. Please follow these steps:

1. Mount Valentine One so that it has a clear view ahead and behind your car, using one of the mounts supplied. For more information on mounting, see pages 14-15.
2. Plug lighter adapter into lighter socket and connect power cord to **Main** jack. For more information on power connections, see page 22.
3. Switch power "on" and adjust volume. For more information on control settings, see pages 16-18.
4. Enjoy Full Coverage radar and laser protection. For more information on interpreting warnings, see pages 4-13.